


1


Den Seifenspender anheben  
Elevate the soap dispenser  
Soulevez le distributeur de savon  
Elevate il dosatore di sapone



2

2

Den Innenbehälter herausnehmen/  
einsetzen  
Take out / put in the inner recipient  
Retirez / remettez le récipient intérieur  
Tirare / rimettere il recipiente interno



1

### STONE SSP




Art. 0972354

Seifenspender - weiß / chrom  
Soap dispenser - white / chrome  
Distributeur de savon - blanc / chrome  
Dosatore di sapone - bianco / cromo

### STONE WSP


Art. 0972254

Wandseifenspender - weiß / chrom  
Soap dispenser wall mounted - white / chrome  
Distributeur de savon mural - blanc / chrome  
Dosatore di sapone da parete - bianco / cromo



### Art. 0009631

Ersatzdrückerplatte - chrom  
Replacement cover - chrome  
Couvercle remplacement - chrome  
Ricambio coperchio - cromo




### Art. 0543000

Ersatzpumpenmechanismus - chrom  
Spare pump mechanism - chrome  
Pompe mécanisme - chrome  
Pompetta meccanismo - cromo



### Art. 0009632

Innenbehälter  
Inner recipient  
Récipient intérieur  
Recipiente interno



### Art. 0008285


Gumming  
Rubber ring  
Caoutchouc  
Anello in gomma



### STONE SSP

Art. 0008246

Behälter - weiß  
Recipient - white  
Récipient - blanc  
Recipiente - bianco



### STONE WSP

Art. 0008247

Behälter - weiß  
Recipient - white  
Récipient - blanc  
Recipiente - bianco

### Art. 0008227

Wandhalterungsset für STONE WSP  
Wall fastening set for STONE WSP  
Set de fixation murale pour STONE WSP  
Set supporto per STONE WSP



DECOR WALTHER